
ENKEL 3P

230V MAX. 3 x 15W E27



Assembly instructions

WARNING: Assembly lamp with the power off.
1. Detach the mounting bracket from the lamp (unscrew the mounting nut from the front of the lamp).
2. Attach the lamp mounting bracket to the ceiling.
3. Connect the power cables to the connection block, tighten clamp screws, close the connection block.
4. Slide the canopy onto the mounting bracket, then tighten the mounting nut.
5. Mount the light sources in the holders.
6. Tighten the lampshades.

Used or broken electrical equipment must not be thrown into the trash bin together with other waste. Used device should be taken to a point of separate collection of municipal waste or a point of utilization of electrical equipment. Proper waste segregation is a very important aspect of environmental protection and must be strictly observed.

WARNING: The installation should be performed by a qualified electrician.

Nowodworcowa 15, 81-581 Gdynia, tel. 736_812_848, info@ummo.pl

UMMO LIGHTING